

MEIKO's K-Series rack conveyors are reliable, quick, and super-efficient. A beacon of MEIKO's commitment to manufacturing excellence, economy of operation, user-friendly concepts, and industry-leading features; the K-Series delivers a superior warewasher that gets you to done.



K-SERIES | Features

- > Low water, energy, and chemical consumption
- > Flush stainless steel panels on all sides
- > Double-wall insulated construction minimizes noise and heat loss, and keeps the exterior cool to the touch
- > Slotted, concave wash arm nozzles minimize clogging, and are computer-positioned for maximum water coverage
- > Unique, patented side-drive system with synchronized pawl bars delivers an unobstructed wash pattern to the top and bottom of each rack
- > Standard vent cowls with double curtains
- > Large separation between wash and rinse zones virtually eliminates splashing of soiled water on sanitized ware
- > Easy cleaning — external drain lever, captivated wash arm end caps, self-positioning wash arm manifolds, front sloping tanks, large pan strainers, wide access doors
- > Fully automatic operation including automatic fill and start, with wash and rinse activated only when a rack is in place, saving water, detergent and energy.
- > Powerful, vertically-installed 3 hp. pump motor(s) are self-draining and easier to service
- > Built in pressure regulating valve on machines with internal booster heater

K-44 Rack Conveyor	K-54 Rack Conveyor	K-64 Rack Conveyor
<p>44" Single Tank</p> <p>CAPACITY: 239 racks/hr., 5,975 dishes/hr.</p> <p>WATER CONSUMPTION: 102 gals./hr., 0.43 gals./rack</p> <p>WASH ARMS: 5 upper, 4 lower</p> <p>WASH PUMP: 3 hp.</p> <p>VOLTAGES: 208V / 60Hz / 3Ph 230V / 60Hz / 3Ph 460V / 60Hz / 3Ph</p> <p>STEAM: Steam coil available</p>	<p>54" Single Tank</p> <p>CAPACITY: 239 racks/hr., 5,975 dishes/hr.</p> <p>WATER CONSUMPTION: 102 gals./hr., 0.43 gals./rack</p> <p>WASH ARMS: 5 upper, 5 lower</p> <p>WASH PUMP: 3 hp.</p> <p>VOLTAGES: 208V / 60Hz / 3Ph 230V / 60Hz / 3Ph 460V / 60Hz / 3Ph</p> <p>STEAM: Steam coil available</p>	<p>64" Multiple Tank</p> <p>CAPACITY: 284 racks/hr., 7,100 dishes/hr.</p> <p>WATER CONSUMPTION: 105 gals./hr., 0.37 gals./rack</p> <p>WASH ARMS: 4 upper, 4 lower</p> <p>RECIRCULATING RINSE ARMS: 4 upper, 4 lower</p> <p>WASH PUMPS: 2 x 3 hp.</p> <p>VOLTAGES: 208V / 60Hz / 3Ph 230V / 60Hz / 3Ph 460V / 60Hz / 3Ph</p> <p>STEAM: Steam coil available</p>
K-66 Rack Conveyor	K-76 Rack Conveyor	K-86 Rack Conveyor
<p>44" Single Tank + 22" Prewash</p> <p>PREWASH ARMS: 2 upper, 1 lower</p> <p>PREWASH PUMP: 3/4 hp.</p> <p>STEAM: Steam coil available</p>	<p>54" Single Tank + 22" Prewash</p> <p>PREWASH ARMS: 2 upper, 1 lower</p> <p>PREWASH PUMP: 3/4 hp.</p> <p>STEAM: Steam coil available</p>	<p>64" Multiple Tank + 22" Prewash</p> <p>PREWASH ARMS: 2 upper, 1 lower</p> <p>PREWASH PUMP: 3/4 hp.</p> <p>STEAM: Steam coil available</p>
K-80 Rack Conveyor	K-90 Rack Conveyor	K-100 Rack Conveyor
<p>44" Single Tank + 36" Prewash</p> <p>PREWASH ARMS: 5 upper, 4 lower</p> <p>PREWASH PUMP: 3 hp.</p> <p>STEAM: Steam coil available</p>	<p>54" Single Tank + 36" Prewash</p> <p>PREWASH ARMS: 5 upper, 4 lower</p> <p>PREWASH PUMP: 3 hp.</p> <p>STEAM: Steam coil available</p>	<p>64" Multiple Tank + 36" Prewash</p> <p>PREWASH ARMS: 5 upper, 4 lower</p> <p>PREWASH PUMP: 3 hp.</p> <p>STEAM: Steam coil available</p>